



## Wi-Fi Countdown Timer Switch

Model – MT10W(NHT06W)

On/off override button  
Push any buttons below to set your countdown time (5min, 10min, 30min, 60min, 2hour, 4hour)  
\* The indicator of your last choice flashes by default.

Hold "5Min" button for 3s to turn off or resume 7 LED indicators.

Hold "2Hour" button for 3s to Dim LED indicators of all 7 buttons.  
\* All LED indicators flash on minimum brightness.

Hold "on/off" button for 3s to exit from countdown mode.  
Push the "on/off" button to resume countdown mode.

Hold "10Min" button for 3s to Dim the LED indicator of on/off button.

Hold "4Hour" button for 3s to brighten LED indicators of all 7 buttons.  
\* All LED indicators flash on maximum brightness.

Hold "30Min" button for 5s, until blue LED indicator flashes quickly, Wi-Fi network configuration is displayed.

Specifications:  
Power: 120VAC, 60Hz / Tungsten: 1200W  
Resistive: 1800W / Motor: 1/2 HP  
Time Delay: 5, 10, 30, 60 mins, 2 or 4 hours  
Humidity: 95% RH, non-condensing  
Operating Temperature: 32° to 131° F (0° to 55° C)

Switch x1  
Wiring x1

If you have any questions, please contact us at



Scan QR code or visit  
ask@minoston.com  
and www.minoston.com

## How it Works

### A Download the app



Scan the QR code above or search Minoston on the Apple App Store or on Google Play



### B Technical Guidance



Amazon-Echo

Google-Home

The Wi-Fi Countdown Timer Switch can be also used with Amazon Echo and Google Home. Please scan the QR code below and follow the instructions if you have any trouble pairing with them.

### C EASY TO SET UP



QR code

### D Voice control

Compatible with Amazon Alexa and Google Assistant



Follow the steps in the Amazon Alexa or Google Assistant app to connect the Minoston app or select "Support" in the Minoston app

### FCC warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation. changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

### CAUTION - PLEASE READ!

This device is intended for installation in accordance with the National Electric Code and local regulations in the United States, or the Canadian Electrical Code and local regulations in

Canada. If you are unsure or uncomfortable about performing this installation consult a qualified electrician.

### MEDICAL EQUIPMENT

Please DO NOT use this plug to control Medical or Life Support equipment. This device should never be used to control the On/Off status of Medical and/or Life Support equipment.

### OTHER WARNINGS

Risk of Fire / Risk of Electrical Shock / Risk of Burns

### IMPORTANT SAFETY INSTRUCTIONS

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
2. Read and follow all instructions that are on the product or provided with the product.
3. do not use an extension cord.
4. Reference the National Electrical Code, NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
5. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
6. do not install or use within 10 feet of a pool

### 8. WARNING:

Risk of Electric Shock.

When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.

### 9. WARNING:

Risk of Electric Shock. Mount the unit at a height greater than 1 foot from the ground surface

### 10. WARNING:

Risk of Electric fire. install only to a receptacle protected by 20A branch circuit over current protection.

SAVE THESE INSTRUCTIONS - This manual contains important safety and operating instructions.